


Pipe Joint Fittings


XQPZA	MODEL(ΦD)	XQPM	MODEL(ΦD)	XQS	MODEL(ΦD-T)
	Tube(Metric)		Tube(Metric)		Tube(Metric)
	XQPZA 04		XQPM 04		XQS 04
	XQPZA 06		XQPM 06		XQS 06
	XQPZA 08		XQPM 08		XQS 08
	XQPZA 10		XQPM 10		XQS 10
	XQPZA 12		XQPM 12		XQS 12

XQI	MODEL(ΦD)	XQC	MODEL(ΦD)
	Tube(Metric)		Tube(Metric)
	XQI 04		XQC 02
	XQI 06		XQC 04
	XQI 08		XQC 06
	XQI 10		XQC 08
	XQI 12		XQC 10



Pipe Fittings


Feature	Specification
When involved in factory maintenance or Plant installation, it's often difficult to be certain which size of fittings will be required. Our Pipe fittings provide a cost effective solution to solve this problem.	Material: Nickel-plated Brass Threads: BSPT, BSPP, NPT, Metric threads Pressure: (See tube) Fluid: Compressed air Temperature: (See data of used tubing)

XPSM	MODEL(ΦT1-ΦT1)					
	Thread(R)T1-Thread(R)T2		Thread(NPT)T1-Thread(NPT)T2		Thread(G)T1-Thread(G)T2	
	XPSM 01-01	XPSM 06-06	XPSM N01-N01	XPSM N06-N06	XPSM G01-G01	XPSM G06-G06
	XPSM 02-02	XPSM 06-04	XPSM N02-N02	XPSM N06-N04	XPSM G02-G02	XPSM G06-G04
	XPSM 02-01	XPSM 06-03	XPSM N02-N01	XPSM N06-N03	XPSM G02-G01	XPSM G06-G03
	XPSM 03-03	XPSM 06-02	XPSM N03-N03	XPSM N06-N02	XPSM G03-G03	XPSM G06-G02
	XPSM 03-02	XPSM 08-08	XPSM N03-N02	XPSM N06-N08	XPSM G03-G02	XPSM G06-G08
	XPSM 03-01	XPSM 08-06	XPSM N03-N01	XPSM N06-N06	XPSM G03-G01	XPSM G06-G06
	XPSM 04-04	XPSM 08-04	XPSM N04-N04	XPSM N06-N04	XPSM G04-G04	XPSM G06-G04
	XPSM 04-03	XPSM 08-03	XPSM N04-N03	XPSM N06-N03	XPSM G04-G03	XPSM G06-G03
	XPSM 04-02		XPSM N04-N02		XPSM G04-G02	
	XPSM 04-01		XPSM N04-N01		XPSM G04-G01	



XPSF	MODEL(ΦT1-ΦT1)					
	Thread(R)T1-Thread(R)T2		Thread(NPT)T1-Thread(NPT)T2		Thread(G)T1-Thread(G)T2	
	XPSF 01-01	XPSF 04-01	XPSF N01-N01	XPSF N04-N01	XPSF G01-G01	XPSF G04-G01
	XPSF 02-02	XPSF 06-06	XPSF N02-N02	XPSF N06-N06	XPSF G02-G02	XPSF G06-G06
	XPSF 02-01	XPSF 06-04	XPSF N02-N01	XPSF N06-N04	XPSF G02-G01	XPSF G06-G04
	XPSF 03-03	XPSF 06-03	XPSF N03-N03	XPSF N06-N03	XPSF G03-G03	XPSF G06-G03
	XPSF 03-02	XPSF 06-02	XPSF N03-N02	XPSF N06-N02	XPSF G03-G02	XPSF G06-G02
	XPSF 03-01	XPSF 08-08	XPSF N03-N01	XPSF N06-N08	XPSF G03-G01	XPSF G06-G08
	XPSF 04-04	XPSF 08-06	XPSF N04-N04	XPSF N06-N06	XPSF G04-G04	XPSF G06-G06
	XPSF 04-03	XPSF 08-04	XPSF N04-N03	XPSF N06-N04	XPSF G04-G03	XPSF G06-G04
	XPSF 04-02	XPSF 08-03	XPSF N04-N02	XPSF N06-N03	XPSF G04-G02	XPSF G06-G03
	XPSF 04-01		XPSF N04-N01		XPSF G04-G01	

Pipe Fittings

XPOF	MODEL(T)		XPEL	MODEL(ΦD-T)	
	Thread(R)	Thread(NPT)		Thread(R)	Thread(NPT)
	XPOF G01	XPOF N01		XPEL 01	XPEL 01N01
	XPOF G02	XPOF N02		XPEL 02	XPEL 02N02
	XPOF G03	XPOF N03		XPEL 03	XPEL 03N03
	XPOF G04	XPOF N04		XPEL 04	XPEL 04N04
	XPOF G06	XPOF N06		XPEL 06	XPEL 06N06
	XPOF G08	XPOF N08		XPEL 08	XPEL 08N08

XPSMF	MODEL(ΦT1-ΦT2)					
	Thread(R)T1-Thread(R)T2		Thread(NPT)T1-Thread(NPT)T2		Thread(G)T1-Thread(G)T2	
	XPSMF 01-01	XPSMF 06-06	XPSMF N01-N01	XPSMF N06-N06	XPSMF G01-G01	XPSMF G06-G06
	XPSMF 02-02	XPSMF 06-04	XPSMF N02-N02	XPSMF N06-N04	XPSMF G02-G02	XPSMF G06-G04
	XPSMF 02-01	XPSMF 06-03	XPSMF N02-N01	XPSMF N06-N03	XPSMF G02-G01	XPSMF G06-G03
	XPSMF 03-03	XPSMF 06-02	XPSMF N03-N03	XPSMF N06-N02	XPSMF G03-G03	XPSMF G06-G02
	XPSMF 03-02	XPSMF 08-08	XPSMF N03-N02	XPSMF N06-N08	XPSMF G03-G02	XPSMF G06-G08
	XPSMF 03-01	XPSMF 08-06	XPSMF N03-N01	XPSMF N06-N06	XPSMF G03-G01	XPSMF G06-G06
	XPSMF 04-04	XPSMF 08-04	XPSMF N04-N04	XPSMF N06-N04	XPSMF G04-G04	XPSMF G06-G04
	XPSMF 04-03	XPSMF 08-03	XPSMF N04-N03	XPSMF N06-N03	XPSMF G04-G03	XPSMF G06-G03
	XPSMF 04-02		XPSMF N04-N02		XPSMF G04-G02	
	XPSMF 04-01		XPSMF N04-N01		XPSMF G04-G01	

XPFL	MODEL(T)		XPRMF	MODEL(ΦT1-ΦT2)		
	Thread(G)	Thread(NPT)		Thread(R)T1-T2	Thread(NPT)T1-T2	Thread(G)T1-T2
	XPFL 01	XPFL N01		XPRMF 02-01	XPRMF N02-N01	XPRMF G02-G01
	XPFL 02	XPFL N02		XPRMF 03-01	XPRMF N03-N01	XPRMF G03-G01
	XPFL 03	XPFL N03		XPRMF 03-02	XPRMF N03-N02	XPRMF G03-G02
	XPFL 04	XPFL N04		XPRMF 04-01	XPRMF N04-N01	XPRMF G04-G01
	XPFL 06	XPFL N06		XPRMF 04-02	XPRMF N04-N02	XPRMF G04-G02
	XPFL 08	XPFL N08		XPRMF 04-03	XPRMF N04-N03	XPRMF G04-G03
				XPRMF 06-02	XPRMF N06-N02	XPRMF G06-G02
				XPRMF 06-03	XPRMF N06-N03	XPRMF G06-G03
		XPRMF 06-04	XPRMF N06-N04	XPRMF G06-G04		

XPEFL	MODEL(T)		XPO	MODEL(T)		
	Thread(R)	Thread(NPT)		Thread(R)	Thread(NPT)	Thread(G)
	XPEFL 01	XPEFL N01		XPO M5	XPO N01	XPO G01
	XPEFL 02	XPEFL N02		XPO 01	XPO N02	XPO G02
	XPEFL 03	XPEFL N03		XPO 02	XPO N03	XPO G03
	XPEFL 04	XPEFL N04		XPO 03	XPO N04	XPO G04
	XPEFL 06	XPEFL N06		XPO 04	XPO N06	XPO G06
	XPEFL 08	XPEFL N08		XPO 06	XPO N08	XPO G08
				XPO 08		

XPOHH	MODEL(T)			XPOH	MODEL(T)		
	Thread(R)	Thread(NPT)	Thread(G)		Thread(R)	Thread(NPT)	Thread(G)
	XPOHH M5	XPOHH N01	XPOHH G01		XPOH M5	XPOH N01	XPOH G01
	XPOHH 01	XPOHH N02	XPOHH G02		XPOH 01	XPOH N02	XPOH G02
	XPOHH 02	XPOHH N03	XPOHH G03		XPOH 02	XPOH N03	XPOH G03
	XPOHH 03	XPOHH N04	XPOHH G04		XPOH 03	XPOH N04	XPOH G04
	XPOHH 04	XPOHH N06	XPOHH G06		XPOH 04	XPOH N06	XPOH G06
	XPOHH 06	XPOHH N08	XPOHH G08		XPOH 06	XPOH N08	XPOH G08
	XPOHH 08				XPOH 08		


Pipe Fittings

XPZ	MODEL(Φ T1- Φ T2)			XPMT	MODEL(T)	
	Thread(R)T1-(G)T2	Thread(NPT)T1-T2	Thread(G)T1-T2		Thread(G)	Thread(NPT)
 <p>In&Out Thread</p>	XPZ 02-G01	XPZ N02-N01	XPZ G02-G01	 <p>Male Stud Branch Tee</p>	XPMT 01	XPMT N01
	XPZ 03-G01	XPZ N03-N01	XPZ G03-G01		XPMT 02	XPMT N02
	XPZ 03-G02	XPZ N03-N02	XPZ G03-G02		XPMT 03	XPMT N03
	XPZ 04-G01	XPZ N04-N01	XPZ G04-G01		XPMT 04	XPMT N04
	XPZ 04-G02	XPZ N04-N02	XPZ G04-G02		XPMT 06	XPMT N06
	XPZ 04-G03	XPZ N04-N03	XPZ G04-G03		XPMT 08	XPMT N08
	XPZ 06-G02	XPZ N06-N02	XPZ G06-G02			
	XPZ 06-G03	XPZ N06-N03	XPZ G06-G03			
	XPZ 06-G04	XPZ N06-N04	XPZ G06-G04			


XPSMT	MODEL(T)		XPSFT	MODEL(T)	
	Thread(G)	Thread(NPT)		Thread(G)	Thread(NPT)
 <p>Male Tee</p>	XPSMT 01	XPSMT N01	 <p>Male To Female Tee</p>	XPSFT 01	XPSFT N01
	XPSMT 02	XPSMT N02		XPSFT 02	XPSFT N02
	XPSMT 03	XPSMT N03		XPSFT 03	XPSFT N03
	XPSMT 04	XPSMT N04		XPSFT 04	XPSFT N04
	XPSMT 06	XPSMT N06		XPSFT 06	XPSFT N06
	XPSMT 08	XPSMT N08		XPSFT 08	XPSFT N08


XPFT	MODEL(T)		XPMST	MODEL(T)	
	Thread(G)	Thread(NPT)		Thread(G)	Thread(NPT)
 <p>Equal Female Tee</p>	XPFT 01	XPFT N01	 <p>Male Run Tee</p>	XPMST 01	XPMST N01
	XPFT 02	XPFT N02		XPMST 02	XPMST N02
	XPFT 03	XPFT N03		XPMST 03	XPMST N03
	XPFT 04	XPFT N04		XPMST 04	XPMST N04
	XPFT 06	XPFT N06		XPMST 06	XPMST N06
	XPFT 08	XPFT N08		XPMST 08	XPMST N08

XPMMT	MODEL(T)		XPYF	MODEL(T)	
	Thread(G)	Thread(NPT)		Thread(G)	Thread(NPT)
 <p>Double Male to Female</p>	XPMMT 01	XPMMT N01	 <p>Female Y</p>	XPYF G01	XPYF N01
	XPMMT 02	XPMMT N02		XPYF G02	XPYF N02
	XPMMT 03	XPMMT N03		XPYF G03	XPYF N03
	XPMMT 04	XPMMT N04		XPYF G04	XPYF N04
	XPMMT 06	XPMMT N06			
	XPMMT 08	XPMMT N08			



XPHTM	MODEL(Φ D-T)					
	Tube(Metric)-Thread(R)		Tube(Metric)-Thread(G)		Tube(Metric)-Thread(NPT)	
 <p>Male Barb</p>	XPHTM05-01	XPHTM10-02	XPHTM05-G01	XPHTM10-G02	XPHTM05-N01	XPHTM10-N02
	XPHTM05-02	XPHTM10-03	XPHTM05-G02	XPHTM10-G03	XPHTM05-N02	XPHTM10-N03
	XPHTM07-01	XPHTM12-02	XPHTM07-G01	XPHTM12-G02	XPHTM07-N01	XPHTM12-N02
	XPHTM07-02	XPHTM12-03	XPHTM07-G02	XPHTM12-G03	XPHTM07-N02	XPHTM12-N03
	XPHTM08-01	XPHTM12-04	XPHTM08-G01	XPHTM12-G04	XPHTM08-N01	XPHTM12-N04
	XPHTM08-02	XPHTM17-03	XPHTM08-G02	XPHTM17-G03	XPHTM08-N02	XPHTM17-N03
	XPHTM09-01	XPHTM17-04	XPHTM09-G01	XPHTM17-G04	XPHTM09-N01	XPHTM17-N04
	XPHTM09-02	XPHTM18-03	XPHTM09-G02	XPHTM18-G03	XPHTM09-N02	XPHTM18-N03
	XPHTM09-03	XPHTM18-04	XPHTM09-G03	XPHTM18-G04	XPHTM09-N03	XPHTM18-N04
	XPHTM10-01		XPHTM10-G01		XPHTM10-N01	



Pipe Fittings

XPHTF	MODEL(Φ D-T)					
	Tube(Metric)-Thread(R)		Tube(Metric)-Thread(G)		Tube(Metric)-Thread(NPT)	
 <p>Female Barb</p>	XPHTF05-01	XPHTF10-02	XPHTF05-G01	XPHTF10-G02	XPHTF05-N01	XPHTF10-N02
	XPHTF05-02	XPHTF10-03	XPHTF05-G02	XPHTF10-G03	XPHTF05-N02	XPHTF10-N03
	XPHTF07-01	XPHTF12-02	XPHTF07-G01	XPHTF12-G02	XPHTF07-N01	XPHTF12-N02
	XPHTF07-02	XPHTF12-03	XPHTF07-G02	XPHTF12-G03	XPHTF07-N02	XPHTF12-N03
	XPHTF08-01	XPHTF12-04	XPHTF08-G01	XPHTF12-G04	XPHTF08-N01	XPHTF12-N04
	XPHTF08-02	XPHTF17-03	XPHTF08-G02	XPHTF17-G03	XPHTF08-N02	XPHTF17-N03
	XPHTF09-01	XPHTF17-04	XPHTF09-G01	XPHTF17-G04	XPHTF09-N01	XPHTF17-N04
	XPHTF09-02	XPHTF18-03	XPHTF09-G02	XPHTF18-G03	XPHTF09-N02	XPHTF18-N03
	XPHTF09-03	XPHTF18-04	XPHTF09-G03	XPHTF18-G04	XPHTF09-N03	XPHTF18-N04
	XPHTF10-01		XPHTF10-G01		XPHTF10-N01	

XPLB	MODEL(Φ D-T)					
	Tube(Metric)-Thread(R)		Tube(Metric)-Thread(G)		Tube(Metric)-Thread(NPT)	
 <p>Male Elbow Barb</p>	XPLB05-01	XPLB10-02	XPLB05-G01	XPLB10-G02	XPLB05-N01	XPLB10-N02
	XPLB05-02	XPLB10-03	XPLB05-G02	XPLB10-G03	XPLB05-N02	XPLB10-N03
	XPLB07-01	XPLB12-02	XPLB07-G01	XPLB12-G02	XPLB07-N01	XPLB12-N02
	XPLB07-02	XPLB12-03	XPLB07-G02	XPLB12-G03	XPLB07-N02	XPLB12-N03
	XPLB08-01	XPLB12-04	XPLB08-G01	XPLB12-G04	XPLB08-N01	XPLB12-N04
	XPLB08-02	XPLB17-03	XPLB08-G02	XPLB17-G03	XPLB08-N02	XPLB17-N03
	XPLB09-01	XPLB17-04	XPLB09-G01	XPLB17-G04	XPLB09-N01	XPLB17-N04
	XPLB09-02	XPLB18-03	XPLB09-G02	XPLB18-G03	XPLB09-N02	XPLB18-N03
	XPLB09-03	XPLB18-04	XPLB09-G03	XPLB18-G04	XPLB09-N03	XPLB18-N04
	XPLB10-01		XPLB10-G01		XPLB10-N01	

XPYT	MODEL(Φ D-T)		XPMFM	MODEL(Φ D-T)	
	Thread(G)	Thread(NPT)		Thread(G)	Thread(NPT)
 <p>Female to Male Y</p>	XPYT 01	XPYT N01	 <p>Female Bulkhead</p>	XPMFM G01	XPMFM N01
	XPYT 02	XPYT N02		XPMFM G02	XPMFM N02
	XPYT 03	XPYT N03		XPMFM G03	XPMFM N03
	XPYT 04	XPYT N04		XPMFM G04	XPMFM N04

XPFC	MODEL(T)		XPBB	MODEL(Φ)
	Thread(G)	Thread(NPT)		Tube
 <p>Equal Female Cross</p>	XPFC G01	XPFC N01	 <p>Barb Union</p>	PBB 05
	XPFC G02	XPFC N02		PBB 07
	XPFC G03	XPFC N03		PBB 08
	XPFC G04	XPFC N04		PBB 09
			PBB 10	
			PBB 12	
			PBB 17	
			PBB 18	

XPFCT	MODEL(T)		XPTB	MODEL(Φ)
	Thread(G)	Thread(NPT)		Tube
 <p>Equal Female To Male Cross</p>	XPFCT 01	XPFCT N01	 <p>Barb T</p>	PTB 05
	XPFCT 02	XPFCT N02		PTB 07
	XPFCT 03	XPFCT N03		PTB 08
	XPFCT 04	XPFCT N04		PTB 09
			PTB 10	
			PTB 12	
			PTB 17	
			PTB 18	